




PDU VIEW Monitoring Software

Monitor the power distribution units in your company with the Axil PDU VIEW Software. This will allow you to set minimum & maximum thresholds for:

- Temperature
- Humidity
- Volts
- Amps
- Watts
- Kilo Watts

Any currents outside these limits will trigger an alert and send a notification to the nominated SMS number or email address. The Axil PDU VIEW Software is available in 3 different versions, depending on the amount of PDU's you need to monitor - 20, 40 or 50 units.



TALK TO US

☎ 0861 000 133

☎ 082 359 7060

☎ 086 540 6273

✉ info@axil.co.za

🌐 www.axil.co.za

📍 KwaZulu-Natal - Durban
Gauteng - Midrand
Cape Town - Montague Gardens

